D-Link® Technical Support Setup Procedure

How to setup DRA-2060 as extender?

Step 1: Connect to current Exo mesh router Wifi. **Step 2:** Open **D-Link Wi-Fi** Apps on the Android mobile device. D-Link Wi-Fi	**Step 3:** Click on **Menu** Icon. Connect to Network 1. Connect to your D-Link Network Go to Settings > Wi-Fi and join your router's Wi-Fi network. 2. Return to D-Link Wi-Fi app Wi-Fi Wi-Fi ✓ D-Link Network CHOOSE A NETWORK...
Step 4: Click on **Install New Device.** ⊕ Install New Device ⊗ My Account ⊚ My Devices ⌄ ⚙ App Settings > ⊟ Privacy Policy >	**Step 5: a)** Click on **Scan the QR code.** **b)** Scan the **QR code** on the device. Locate the setup QR code. Help me to find the QR code SETUP QR CODE Scan the QR code Continue without scanning
Step 6: a) Ensure you are connected to your **Wi-Fi Network.** **b)** Click on **Next** Connect to Your Wi-Fi Network Please make sure you are connected to your home Wi-Fi network. NEXT	**Step 7:** Wait for **Detecting device** to finish. Detecting device

| **Step 8:** Click **SELECT** under **Wirelessly.**	**Step 9: a)** Place **DRA-2060** between your router and the area where you want wireless coverage. **b)** Click on **NEXT.**
How would you like to extend your Wi-Fi network? Wirelessly Extender Router The device acts as a wireless range extender, extending your router's wireless signal. SELECT	Place your Device Place the device anywhere between your router and the area where you want wireless coverage. NEXT
Step 10: a) Power on the device. **b)** Click on **NEXT.**	**Step 11:** Wait for **device** to boot up.
Power up Your Device Plug the device into an available power outlet and tap NEXT. NEXT	3 % The device is now booting up. This might take a few minutes.
Step 12: a) Ensure the LED at the side of the device start to blink orange. **b)** Click on **NEXT.**	**Step 13:** Wait for your **mobile device** to connect to **DRA-2060.**
Ready for Configuration When the LED starts **blinking orange**, tap NEXT. NEXT	Connecting to your device ...

Step 14: a) Select **Wi-Fi** network.
    b) Click on **NEXT.**
 	
Extend Your Wi-Fi
 	
Select the Wi-Fi network you would like to extend.
 	
(^(.)^)
OSC992A
muhd14
✓ Dunudare5
SINGTEL-DCAE
1960
muhd14
mooyong
OSC992A
Linksys15551_5GHz
 	
NEXT
	Step 15: a) Enter the **Wi-Fi Password.**
	    b) Click on **NEXT.**
	
	Network Password
	
	Enter the Wi-Fi password of **Dunudare5**
	
	NEXT

Step 16: Click on **NEXT.** Extended Network Enter a name and password for your device extended Wi-Fi Network. Dunudare5-EXT ◯ Copy Connected Wi-Fi **NEXT**	**Step 17: a)** Give a **device password.** **b)** Click on **NEXT.** Protect Your Device Give your device an admin password. This password is used to make changes to your device's settings through the D-Link Wi-Fi app and the device's web based user interface. **NEXT**
Step 18: Click on **NEXT.** **Install Updates Automatically** This allows D-Link Wi-Fi to automatically update your device for you to make sure you are always enjoying the latest features and improvements. ● Keep my device up to date automatically. ◯ I want to manage the device updates myself. **NEXT**	**Step 19:** Click on **SAVE.** Almost there … Tap **SAVE** to apply these settings and reboot the device. Please **do not** unplug the device until it has fully rebooted. ⓘ **Device Password** **Connected Network** 🛜 Dunudare5 🔒 **Extended Network** 🛜 Dunudare5-EXT 🔒 Make a note of this information for future reference. **SAVE**

Step 20: Wait for Setting to be save.	**Step 21: a)** Ensure the LED at the side of the device light up **Solid Green.** **b)** Click on **NEXT.**
Step 22: Click on NEXT.	**Step 23: a) Give a device password.** **b) Click on NEXT.**
Step 24: Click on NEXT.	**Step 25: Click on SAVE.**

--- END ---