How to setup multi-zone motion detection recording?

Step 1: Connect the power of the camera.

Step 2: Open Mydlink apps on the mobile device.



Step 3: Enter the register Mydlink **Username and password.**




Step 4: Click on the Menu Icon.




Step 5: Click on Devices




Step 6: Click on Camera.




Step 7: Click on Setting Icon.







Step 9: Click on Multi-Zone Motion Detection.



Step 10: a) Click on the live view streams to select or move the detected zones.

b) Move the slider to adjust the sensitivity level for motion detection.



Step 11: a) Press **Back** on your mobile device for **5 Time** and go back to the main page


- b) Click on the Menu Icon.
- c) Click on Settings.




Step 12: Click on Automation icon.



Step 13: Click on the Add Icon,



D-Line Technical Support Setup Procedure



--- END ---