How to configure Unifi/Maxis/Time on DSL-G2452DG?


Step 1: Open an Internet browser (such as Internet Explorer/Chrome) and enter http://192.168.1.1, into the address bar.



Step 2: Enter your login information. If you have not changed the default settings, the username & password field should be admin/admin. Click **Login**.




Step 3: Click the **Quick Setup** from the left menu list.



Step 4: Select your Connection type from the list below (We will use **TM Unifi** as example). Click **Next**

Quick Setup



Setup 5: Select the WAN mode

VDSL if you Unifi are connected to your VDSL port (Grey Colour DSL Port to ISP)


WAN if your Unifi are connected to your WAN port (<u>Blue</u> Colour Ethernet Port to ISP)

Fill in your **Username** and **Password** (Please get it from your ISP if you are not sure)

Please check IPv6 if you would like to use IPv6 with this ISP


Click Next

Quick Setup



Step 6: Wi-Fi Setup, please fill in the required WI-FI SSID and Password. Uncheck to Disable the Wi-Fi.

Quick Setup



Step 7: VoIP Setup, please fill in your VoIP info (Please check with your ISP for this info)

Uncheck to Disable.

VoIP on (LAN3) will bridge VoIP traffic for LAN3

IPTV on (LAN4) will bridge IPTV traffic to LAN 4 (Default Enable)


Quick Setup

step1 -> ste	p2 -> step3 -> step4 -> step5	
VoIP 1:		
Username:	+60312345678@ims.tm.	
Password:	12345678 ×	
VoIP 2:		
Username:	@ims.tm.com.my	
Password:		
VoIP on (LAN3):		
IPTV on (LAN4):		
Back Next		

Step 8: Admin Password, Click Apply


Checked and filled in the NewPassword.

Quick Setup



Step 9: Click **YES** and device will reboot with the new setting.

Click on Applications - VoIP - Basic Setup



FAQ:

How can I change the VoIP provider to other provider?
 Click under Basic Setup – WAN Service
 Click on the Connection Name (VDSL_3_1 Which have the VLAN ID 400)
 WAN Service

Connection Name:	VDSL_3_1	x V
Mode:	PTM 💙	
Enable:	✓	
Mode:	Con-Bridge ∨	
VLAN PassThrough:		
Enable VLAN:	✓	
VLAN ID:	400	
Click on Delete to delete	it.	
Click on the Connection	Name (VDSL_1_1 Which ha	ve the VLAN ID 500/Your Default ISF
VLAN ID)		
Change the Services Typ	e from INTERNET	
Service Type:	INTERNET	~
Change to INTERNET_VC	DIP	
Service Type:	INTERNET_VOIP	~
Click Apply When done.		

➤ Applications ➤ Storage Service Telnet Service SSH Service Printer Share Multimedia Share ➤ DNS UPnP ➤ Multicast SNMP ▼ VoIP

Basic Setup

Change the VOIP Server and also username and password Basic Setup

	Port:	5060	(102	24 ~ 65535)	
/	Register Server:	ims.tm.com.my			\
	Proxy:	10.255.0.1]		
	Outbound Server:	10.255.0.1			
	Port:	5060	(102	24 ~ 65535)	
	Backup Register Server:	ims.tm.com.my			
	Backup Porxy:	10.255.0.1			
	Backup Outbound Server:	10.255.0.1			
	Backup Port:	5060	(102	24 ~ 65535)	
	Register Life TIme:	1200	Sec	ond	
	Enable Link Test:		•		
	Link Test Interval:	20		Second	
	Retry Interval:	3600		Second	
	Enable P-Asserted-Identity	: 			

Connection 1

Enable:	✓
User Name:	+60312345678@ims.tm.i
Password:	•••••

Click Apply When done.